



obj.č.

6571

Misa okrúhla

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	32	32	3	8 5 8 4 0 2 4 1 0 0 1 9 4 3 1



obj.č.

6285

Misa delená

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	28,5	28,5	2	8 5 8 4 0 2 4 1 0 0 1 1 4 1 1



obj.č.

6608**23x23 cm**

Podnos

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	23	23	2	8 5 8 4 0 2 4 1 0 0 2 1 4 8 1



obj.č.

6406

Podnos Donald

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	39	27	2,5	8 5 8 4 0 2 4 1 0 0 1 5 1 8 1



obj.č.

6801**48x33 cm**

Podnos s protišmykovou úpravou

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	48	33	3	8 5 8 4 0 2 4 1 0 0 2 9 4 0 1



obj.č.

6399

Podnos oválny

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	38	26,5	2	8 5840241001301



obj.č.

6562

∅ 24,5 cm

Kryt do mikrovlnky

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	24,5	24,5	7	8 5840241001882



obj.č.

6469

malá

6470

stredná

6471

veľká

6472

sada

Miska hranatá

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	20,5	14,5	3,5	8 5840241001523
1	28	17	3,5	8 5840241001530
1	34,5	23,5	4	8 5840241001547
3	-	-	-	8 5840241001752



obj.č.

6269

Dvojdielny príborník

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	34	27,5	6,5	8 5840241001158



obj.č.

6770

Príborník

ks	rozmery (cm)			EAN
	dĺžka	šírka	výška	
1	33	25	5,5	8 5840241002766